# SIT 221 – Event Driven Programming

EXPLORING THE VISUAL BASIC .NET TOOLBOX

### **Function Overloading**

- Overloading lets a function vary its behavior based on its input arguments.
- Visual Basic .NET will have multiple functions with the same name, but with different argument lists.
- The different argument lists may have different numbers of arguments and different types of arguments.

#### What are the implications of overloading?


- What this means to us is that when using a Visual Basic .NET function, there will be several different ways to use that function.
- Another implication is that, when typing code for a function, the Intellisense feature of the Visual Basic .NET IDE will appear with a drop-down list of all implementations of a particular function. As you type in your implementation, Intellisense adjusts to the particular form of the function it "thinks" you are using.

Overloading is a powerful feature of Visual Basic .NET.

# MessageBox Dialog

- One of the most often used functions in Visual Basic .NET is the MessageBox function.
- This function lets you display messages to your user and receive feedback for further information.
- It can be used to display error messages, describe potential problems or just to show the result of some computation.
- The MessageBox function is versatile, with the ability to display any message, an optional icon, and a selected set of buttons.
- The user responds by clicking a button in the message box

# Example



To use the MessageBox function, you decide what the Text of the message should be, what Caption you desire, what Icon and Buttons are appropriate, and which DefaultButton you want. To display the message box in code, you use the MessageBox Show method.

The MessageBox function is **overloaded** with several ways to implement the **Show** method. Some of the more common ways are:

- ✓ MessageBox.Show(Text)
- ✓ MessageBox.Show(Text, Caption)
- MessageBox.Show(Text, Caption, Buttons)
- ✓ MessageBox.Show(Text, Caption, Buttons, Icon)
- ✓ MessageBox.Show(Text, Caption, Buttons, Icon, DefaultButton)

In these implementations, if **DefaultButton** is omitted, the first button is default. If **Icon** is omitted, no icon is displayed. If **Buttons** is omitted, an 'OK' button is displayed. And, if **Caption** is omitted, no caption is displayed.

- You decide what you want for the message box **Text** and **Caption** information (string data types). The other arguments are defined by Visual Basic .NET predefined constants.
- The Buttons constants are defined by the MessageBoxButtons constants:

Member	Description
AbortRetryIgnore	Displays Abort, Retry and Ignore buttons
OK	Displays an OK button
OKCancel	Displays OK and Cancel buttons
RetryCancel	Displays Retry and Cancel buttons
YesNo	Displays Yes and No buttons

YesNoCancel

Displays Yes, No and Cancel buttons

The syntax for specifying a choice of buttons is the usual dot-notation:

MessageBoxButtons.Member

So, to display an OK and Cancel button, the constant is:

MessageBoxButtons.OKCancel

### The displayed Icon is established by the **MessageBoxIcon** constants:

Member	Description	
IconAsterisk	Displays an information icon	
IconInformation	Displays an information icon	
IconError	Displays an error icon (white X in red circle)	
IconHand	Displays an error icon	To specify an icon, the syntax is:
IconNone	Display no icon	MessageBoxIcon.Member
IconStop	Displays an error icon	Note there are eight different
IconExclamation	Displays an exclamation point icon	members of the MessageBoxIcon
IconWarning	Displays an exclamation point icon	constants, but only four icons (information, error, exclamation,
IconQuestion	Displays a question mark icon	question) available.

When a message box is displayed, one of the displayed buttons will have focus or be the default button. If the user presses <Enter>, this button is selected. You specify which button is default using the MessageBoxDefaultButton constants:

Member	Description
DefaultButton1	First button in message box is default
DefaultButton2	Second button in message box is default
DefaultButton3	Third button in message box is default

To specify a default button, the syntax is:

MessageBoxDefaultButton.Member

When you invoke the Show method of the MessageBox function, the function returns a value from the **DialogResult** constants. The available members are:

Member	Description
Abort	The Abort button was selected
Cancel	The Cancel button was selected
Ignore	The Ignore button was selected
No	The No button was selected
OK	The OK button was selected
Retry	The Retry button was selected
Yes	The Yes button was selected

### **Example 1**: - Rectify the code


*If MessageBox.Show* 

("This is an example of a message box", "Message Box Example", MessageBoxButtons.OKCancel, messageBoxIcon.Information, MessageBoxDefaultButton 'everything is OK

Else

'cancel was pressed

End If



Of course, you would need to add code for the different tasks depending on whether OK or Cancel is clicked by the user.

### Example 2:

Many times, you just want to display a quick message to the user with no need for feedback (just an OK button). This code does the job:

MessageBox.Show("Quick message for you.", "Hey You!")


The resulting message box:



Notice there is no icon and the OK button (default if no button specified) is shown.

Also, notice in the code, there is no need to read the returned value – we know what it is! You will find a lot of uses for this simple form of the message box (with perhaps some kind of icon) as you progress in Visual Basic .NET.

# Form Object



The **Form** is the object where the user interface is drawn. It is central to the development of Visual Basic .NET applications.

The form is known as a **container** object, since it 'holds' other controls.

One implication of this distinction is that controls placed on the form will share **BackColor**, **ForeColor** and **Font** properties.

To change this, select the desired control (after it is placed on the form) and change the desired properties. Another feature of a container control is that when its Enabled property is False, all controls in the container are disabled.

### Properties, Methods and Events for the form

Recall **properties** described the appearance and value of a control, **methods** are actions you can impose on controls and **events** occur when something is done to the control (usually by a user).

#### **Form Properties:**

**Name** Gets or sets the name of the form (three letter prefix for form name is **frm**).

**AcceptButton** Gets or sets the button on the form that is clicked when the user presses the <Enter> key.

**BackColor** Get or sets the form background color.

**CancelButton** Gets or sets the button control that is clicked when the user presses the <Esc> key.

**ControlBox** Gets or sets a value indicating whether a control box is displayed in the caption bar of the form.

**Enabled** If False, all controls on form are disabled.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text or graphics.

**FormBorderStyle** Sets the form border to be fixed or sizeable.

**Height** Height of form in pixels.

**Help** Gets or sets a value indicating whether a Help button should be displayed in the caption box of the form.

**Icon** Gets or sets the icon for the form.

**Left** Distance from left of screen to left edge of form, in pixels.

MaximizeButton form.

Gets or sets a value indicating whether the maximize button is displayed in the caption bar of the

MinimizeButton form.

Gets or sets a value indicating whether the minimize button is displayed in the caption bar of the

**StartPosition** Gets or sets the starting position of the form when the application is running.

**Text** Gets or sets the form window title.

**Top** Distance from top of screen to top edge of form, in pixels.

**Width** Width of form in pixels.

#### Form Methods:

**Close** Closes the form.

**Focus** Sets focus to the form.

**Hide** Hides the form.

**Refresh** Forces the form to immediately repaint itself.

**Show** Makes the form display by setting the Visible property to True.

The normal syntax for invoking a method is to type the control name, a dot, then the method name. For form methods, the name to use is **Me**. This is a Visual Basic .NET keyword used to refer to a form. Hence, to close a form, use:

Me.Close()

#### Form Events:

**Activated** Occurs when the form is activated in code or by the user.

**Click** Occurs when the form is clicked by the user.

**Closing** Occurs when the form is closing.

**DoubleClick** Occurs when the form is double clicked.

**Load** Occurs before a form is displayed for the first time.

**Paint** Occurs when the form is redrawn.


To access a form event in the Code window, select the Base Class Events object, then the event.

### **Button Control**

#### In Toolbox:



#### On Form (Default Properties):



It is probably the most widely used Visual Basic .NET control. It is used to begin, interrupt, or end a particular process.

#### **Button Properties:**

Name Gets or sets the name of the button (three letter prefix for button name is btn).

**BackColor** Get or sets the button background color.

**Enabled** If False, button is visible, but cannot accept clicks.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text or graphics.

**Image** Gets or sets the image that is displayed on a button control.

**Text** Gets or sets string displayed on button.

**TextAlign** Gets or sets the alignment of the text on the button control.

#### **Button Methods:**

**Focus** Sets focus to the button.

**PerformClick** Generates a Click event for a button.

#### **Button Events:**

**Click** Event triggered when button is selected either by clicking on it or by pressing

the access key.

**DblClick** Event triggered when user double-clicks on a label.

Typical use of **Label** control for changing display:

Set the Name property. Initialize Text to desired string.

Assign **Text** property (String type) in code where needed.

You may also want to change the **Font**, **Backcolor** and **Forecolor** properties.

### **TextBox Control**

A **TextBox** control is used to display information entered at design time, by a user at run-time, or assigned within code. The displayed text may be edited.

#### **TextBox Properties:**

Name Gets or sets the name of the text box (three letter prefix for text box name is txt).

**AutoSize** Gets or sets a value indicating whether the height of the text box automatically

adjusts when the font assigned to the control is changed.

**BackColor** Get or sets the text box background color.

**BorderStyle** Gets or sets the border style for the text box.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text or graphics.

**HideSelection** Gets or sets a value indicating whether the selected text in the text box control

remains highlighted when the control loses focus.

**Lines** Gets or sets the lines of text in a text box control.

**MaxLength** Gets or sets the maximum number of characters the user can type into the text

box control.

**MultiLine** Gets or sets a value indicating whether this is a multiline text box control.

PasswordChar Gets or sets the character used to mask characters of a password in a single-

line TextBox control.

**ReadOnly** Gets or sets a value indicating whether text in the text box is read-only.

**ScrollBars** Gets or sets which scroll bars should appear in a multiline TextBox control.

**SelectedText** Gets or sets a value indicating the currently selected text in the

control.

**SelectionLength** Gets or sets the number of characters selected in the text box.

**SelectionStart** Gets or sets the starting point of text selected in the text box.

Tag Stores a string expression.

**Text** Gets or sets the current text in the text box.

**TextAlign** Gets or sets the alignment of text in the text box.

**TextLength** Gets length of text in text box.

#### **TextBox Methods:**

**AppendText** Appends text to the current text of text box.

**Clears** Clears all text in text box.

**Copy** Copies selected text to clipboard.

**Cut** Moves selected text to clipboard.

**Focus** Places the cursor in a specified text box.

**Paste** Replaces the current selection in the text box with the contents of the

Clipboard.

**SelectAll** Selects all text in text box.

**Undo** Undoes the last edit operation in the text box.

#### **TextBox Events:**

Click	Occurs when the user clicks the text box.
Enter	Occurs when the control receives focus.
KeyDown	Occurs when a key is pressed down while the control has focus.
KeyPress	Occurs when a key is pressed while the control has focus – used for key trapping.
Leave	Triggered when the user leaves the text box. This is a good place to examine the contents of a text box after editing.
TextChanged	Occurs when the Text property value has changed.


#### Typical use of **TextBox** control as input device:

- Set the **Name** property. Initialize **Text** property to desired string.
- If it is possible to input multiple lines, set **MultiLine** property to **True**.
- In code, give **Focus** to control when needed. Provide key trapping code in **KeyPress** event. Read **Text** property when **Leave** event occurs.
- You may also want to change the Font, Backcolor and Forecolor properties.

### Example - Password Validation

Start a new project. The idea of this project is to ask the user to input a password. If correct, a message box appears to validate the user. If incorrect, other options are provided.

Place a two buttons, a label box, and a text box on your form so it looks something like this:



Set the properties of the form and each object.

Form1:

Name frmPassword

AcceptButton btnValid

CancelButton btnExit

FormBorderStyle FixedSingle

StartPosition CenterScreen

Text Password Validation

Label1:

BorderStyle Fixed3D

Font Size 10

Font Style Bold

Text Please Enter Your Password:

TextAlign MiddleCenter

Text1:

Name txtPassword

Font Size 14

PasswordChar

Tag [Whatever you choose as a password]

Text [Blank]

**Button1:** 


Name btnValid

Text & Validate

**Button2:** 

Name btnExit

Text E&xit



```
Private Sub btnValid_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles btnValid.Click
  'This procedure checks the input password
 Dim Response As DialogResult
 If txtPassword.Text = CStr(txtPassword.Tag) Then
   'If correct, display message box
  MessageBox.Show("You've passed security!", "Access Granted", MessageBoxButtons.OK, MessageBoxIcon.Exclamation)
 Else
  'If incorrect, give option to try again
   Response = MessageBox.Show("Incorrect password", "Access Denied", MessageBoxButtons.RetryCancel, MessageBoxIcon.Error)
  If Response = DialogResult.Retry Then
    txtPassword.SelectionStart = 0
    txtPassword.SelectionLength = Len(txtPassword.Text)
   Else
    Me.Close()
   End If
                                                                    btnValid Click event
  End If
 txtPassword.Focus()
```

**End Sub** 

This code checks the input password to see if it matches the stored value. If so, it prints an acceptance message.

If incorrect, it displays a message box to that effect and asks the user if they want to try again. If Yes (Retry), another try is granted.

If No (Cancel), the program is ended. Notice the use of **SelectionLength** and **SelectionStart** to highlight an incorrect entry. This allows the user to type right over the incorrect response.

# frmPassword\_Load event

Private Sub frmPassword\_Load(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles MyBase.Load

'make sure focus starts in text box

txtPassword.Focus()

**End Sub** 

# btnExit\_ Click event

Private Sub btnExit\_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles btnExit.Click

Me.Close()

**End Sub** 

### Run the program





Define a constant, TRYMAX = 3, and modify the code to allow the user to have just TRYMAX attempts to get the correct password. After the final try, inform the user you are logging him/her off. You'll also need a variable that counts the number of tries (make it a **Static** variable).

### CheckBox Control

The **CheckBox** control provides a way to make choices from a list of potential candidates. Some, all, or none of the choices in a group may be selected.

Check boxes are used in all Windows applications (even the Visual Basic .NET IDE).

Examples of their use would be to turn options on and off in an application or to select from a 'shopping' list.

#### **CheckBox Properties:**

Name Gets or sets the name of the check box (three letter prefix for check box name is **chk**).

**BackColor** Get or sets the check box background color.

**Checked** Gets or sets a value indicating whether the check box is in the checked state.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text or graphics.

**Text** Gets or sets string displayed next to check box.

**TextAlign** Gets or sets the alignment of text of the check box.

#### **CheckBox Methods:**

**Focus** Moves focus to this check box.

#### **CheckBox Events:**

**CheckedChange**Occurs when the value of the Checked property changes, whether in code or when a check box is clicked.

Click Triggered when a check box is clicked. Checked property is automatically changed by Visual Basic .NET.

When a check box is clicked, if there is no check mark there (Checked = False), Visual Basic .NET will place a check there and change the Checked property to True. If clicked and a check mark is there (Checked = True), then a check mark will appear and the Checked property will be changed to False.

### RadioButton Control

**RadioButton** controls provide the capability to make a "mutually exclusive" choice among a group of potential candidate choices. This simply means, radio buttons work as a group, only one of which can be selected. Radio buttons are seen in all Windows applications.

They are called radio buttons because they work like a tuner on a car radio – you can only listen to one station at a time! Examples for radio button groups would be twelve buttons for selection of a month in a year, a group of buttons to let you select a color or buttons to select the difficulty in a game.

A first point to consider is how do you define a 'group' of radio buttons that work together? Any radio buttons placed on the form will act as a group. That is, if any radio button on a form is 'selected', all other buttons will be automatically 'unselected.'

What if you need to make two independent choices; that is, you need two independent groups of radio buttons? To do this requires one of two grouping controls in Visual Basic .NET: the **GroupBox** control or the **Panel** control. Radio buttons placed on either of these controls are independent from other radio buttons.

#### **RadioButton Properties:**

Name Gets or sets the name of the radio button (three letter prefix for radio button name is rdo).

**BackColor** Get or sets the radio button background color.

Checked Gets or sets a value indicating whether the radio button is checked.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text or graphics.

**TextAlign** Gets or sets the alignment of text of the radio button.

#### **RadioButton Methods:**

**Focus** Moves focus to this radio button.

**PerformClick** Generates a Click event for the button, simulating a click by a user.

#### **RadioButton Events:**

**CheckedChange** Occurs when the value of the Checked property changes, whether in code or

when a radio button is clicked.

**Click** Triggered when a button is clicked. **Checked** property is automatically

changed by Visual Basic .NET.

#### Typical use of **RadioButton** control:

Establish a group of radio buttons.

For each button in the group, set the **Name** (give each button a similar name to identify them with the group) and **Text** property. You might also change the **Font**, **BackColor** and **Forecolor** properties.

Initialize the **Checked** property of one button to **True**.

Monitor the **Click** or **CheckChanged** event of each radio button in the group to determine when a button is clicked. The 'last clicked' button in the group will always have a **Checked** property of **True**.

### **GroupBox Control**

We've seen that both radio buttons and check boxes usually work as a group. Many times, there are logical groupings of controls. For example, you may have a scroll device setting the value of a displayed number. The **GroupBox** control provides a convenient way of grouping related controls in a Visual Basic .NET application. And, in the case of radio buttons, group boxes affect how such buttons operate.

To place controls in a group box, you first draw the GroupBox control on the form. Then, the associated controls must be placed in the group box. This allows you to move the group box and controls together. There are several ways to place controls in a group box:

Place controls directly in the group box using any of the usual methods.

Draw controls outside the group box and drag them in.

Copy and paste controls into the group box (prior to the paste operation, make sure the group box is selected).

To insure controls are properly place in a group box, try moving it and make sure the associated controls move with it. To remove a control from the group box, simple drag it out of the control.

#### **GroupBox Properties:**

Name Gets or sets the name of the group box (three letter prefix for group box name is grp).

**BackColor** Get or sets the group box background color.

**Enabled** Gets or sets a value indicating whether the group box is enabled. If False, all controls

in the group box are disabled.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text.

**Text** Gets or sets string displayed in title region of group box.

Visible If False, hides the group box (and all its controls).

### **Panel Control**

The **Panel** control is another Visual Basic .NET grouping control. It is nearly identical to the **GroupBox** control in behavior. The Panel control lacks a Text property (titling information), but has optional scrolling capabilities.

Controls are placed in a Panel control in the same manner they are placed in the GroupBox. And, radio buttons in the Panel control act as an independent group. Panel controls can also be used to display graphics (lines, curves, shapes, animations). We will look at those capabilities in later chapters.

#### **Panel Properties:**

Name Gets or sets the name of the panel (three letter prefix for panel name is pnl).

**AutoScroll** Gets or sets a value indicating whether the panel will allow the user to scroll to any

controls placed outside of its visible boundaries.

**BackColor** Get or sets the panel background color.

**BorderStyle** Get or set the panel border style.

**Enabled** Gets or sets a value indicating whether the panel is enabled. If False, all controls in the

panel are disabled.

**Visible** If False, hides the panel (and all its controls).

## Handling Multiple Events in a Single Event Procedure

Now that we are grouping controls like check boxes and radio buttons, it would be nice if a single procedure could handle multiple events.

For example, if we have 4 radio buttons in a group, when one button is clicked, it would be preferable to have a single procedure where we decide which button was clicked, as opposed to having to monitor 4 separate event procedures.

Assume we have four radio buttons (RadioButton1, RadioButton2, RadioButton3, RadioButton4). The form for the CheckedChanged event procedure for RadioButton1 is:

Private Sub RadioButton1\_CheckedChanged(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles RadioButton1.CheckedChanged

•

•

The name assigned to this procedure by Visual Basic .NET (RadioButton1\_CheckedChanged) is arbitrary. We could change it to anything we want and it would still handle the CheckedChanged event for RadioButton1. Why, you ask?

The important clause in the procedure structure is the **Handles** statement:

#### Handles RadioButton1.CheckedChanged

This clause assigns the **RadioButton1.CheckedChanged** event to this particular procedure. This clause cannot be changed. We can assign additional events to this procedure by appending other control events to the **Handles** clause. For example, if we want this procedure to also handle the **CheckedChanged** event for **RadioButton2**, we can change the clause to:

#### Handles RadioButton1.CheckedChanged, RadioButton2.CheckedChanged

Then if either of these two radio buttons is clicked (changing the Checked property), the procedure named RadioButton1\_CheckedChanged will be invoked.

### The code that does this is:

Private Sub MyButtons\_CheckedChanged(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles RadioButton1.CheckedChanged, RadioButton2.CheckedChanged, RadioButton3.CheckedChanged, RadioButton4.CheckedChanged

.

\_

In our example with a single procedure handling the CheckedChanged event for 4 radio buttons, how do we know which of the 4 buttons was clicked to enter the procedure? The **sender** argument of the event procedure provides the answer.

Each event procedure has a **sender** argument (the first argument of two) which identifies the control whose event caused the procedure to be invoked. With a little BASIC coding, we can identify the **Name** property (or any other needed property) of the sending control. For our radio button example, that code is:

Dim rdoExample As RadioButton

Dim ButtonName As String

'Determine which button was clicked

rdoExample = CType(sender, RadioButton)

ButtonName = rdoExample.Name

## **Control Arrays**

When using controls that work in groups, like check boxes and radio buttons, it is sometimes desirable to have some way to quickly process every control in that group. A concept of use in this case is that of a **control array**.

Say we have 10 check boxes (chkBox01, chkBox02, chkBox03, chkBox04, chkBox05, chkBox06, chkBox07, chkBox08, chkBox09, chkBox10) on a form and we need to examine each check box's Checked property. If that property is True, we need to process 30 lines of additional code. For one check box, that code would be:

If chkBox01.Checked Then

[do these 30 lines of code]

**End If** 

Here's the solution. Define an array of 10 check box controls and assign the array values to existing controls:

#### Dim MyCheck(10) As CheckBox

MyCheck(1) = chkBox01

MyCheck(2) = chkBox02

MyCheck(3) = chkBox03

MyCheck(4) = chkBox04

MyCheck(5) = chkBox05

MyCheck(6) = chkBox06

MyCheck(7) = chkBox07

MyCheck(8) = chkBox08

MyCheck(9) = chkBox09

MyCheck(10) = chkBox10

## Example - Pizza Order

Start a new project. We'll build a form where a pizza order can be entered by simply clicking on check boxes and radio buttons.

Draw three group boxes. In the first, draw three radio buttons, in the second, draw two radio buttons, and in the third, draw six check boxes. Draw two radio buttons on the form.

Add two buttons. Make things look something like this.

Form1		_
GroupBox1	GroupBox3	· · · · · · · · · · · · · · · · · · ·
::   C RadioButton1	: CheckBox1	:
📋 : 🔿 RadioButton2 🔠 🚞		<u> </u>
:: C RadioButton3 ::::	∴ CheckBox2	: CheckBox5 ::::::::
	: CheckBox3	☐ CheckBox6
GroupBox2		
:: C RadioButton4	·	· · · · · · · · · · · · · · · · · · ·
:: C RadioButton5	: : : C RadioButton6	C RadioButton7
Button1	[:::::	Button2
<del> </del>	<del></del> <del></del>	· · · · · · · · · · · · · · · · · · ·

# Set the properties of the form and each control

Form1:					RadioBut	ton3:	
	Name		frmPizza			Name	rdoLarge
	FormBord	lerStyle	FixedSingle			Text	Large
	StartPosition		CenterScreen		RadioButton4:		
	Text		Pizza Order			Name	rdoThin
GroupBox1:			Checked	True			
	Text	Size				Text	Thin Crust
GroupBox2:			RadioButton5:				
	Text	Crust Typ	е			Name	rdoThick
GroupBox3			Text	Thick Crust			
	Text Toppings		RadioButton6:				
RadioButton1:			Name	rdoIn			
	Name	rdoSmall				Checked	True
	Checked	True				Text	Eat In
	Text	Small		RadioButton7:			
RadioButton2:			Name	rdoOut			
	Name	rdoMediu	ım			Text	Take Out
	Text	Medium					

CheckBox1:

Name chkCheese Text Extra Cheese

CheckBox2:

Name chkMushrooms Text Mushrooms

CheckBox3:

Name chkOlives Text Black Olives

CheckBox4:

Name chkOnions Text Onions CheckBox5:

Name chkPeppers Text Green Peppers

CheckBox6:


Name chkTomatoes Text Tomatoes

**Button1**:

Name btnBuild
Text &Build Pizza

**Button2**:

Name btnExit Text E&xit



## Form level scope variable declarations:

Dim PizzaSize As String

Dim PizzaCrust As String

Dim PizzaWhere As String

Dim Topping(6) As CheckBox

This makes the size, crust, and location variables global to the form. The array of check box controls will help us determine which toppings are selected.

## Use this code in the Form\_Load procedure

Private Sub frmPizza\_Load(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles MyBase.Load

```
'Initialize parameters
```

PizzaSize = rdoSmall.Text

PizzaCrust = rdoThin.Text

PizzaWhere = rdoIn.Text

'Define an array of topping check boxes

Topping(1) = chkCheese

Topping(2) = chkMushrooms

Topping(3) = chkOlives

Topping(4) = chkOnions

Topping(5) = chkPeppers

Topping(6) = chkTomatoes

## Single CheckedChanged events

Private Sub rdoSize\_CheckedChanged(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles rdoSmall.CheckedChanged, rdoMedium.CheckedChanged, rdoLarge.CheckedChanged

Dim rdoSize As RadioButton

'Determine which button was clicked and change size

rdoSize = CType(sender, RadioButton)

PizzaSize = rdoSize.Text

Private Sub rdoCrust\_CheckedChanged(ByVal sender As Object, ByVal e As System.EventArgs) Handles rdoThin.CheckedChanged, rdoThick.CheckedChanged

Dim rdoCrust As RadioButton

'Determine which button was clicked and change crust

rdoCrust = CType(sender, RadioButton)

PizzaCrust = rdoCrust.Text

Private Sub rdoWhere\_CheckedChanged(ByVal sender As Object, ByVal e As System.EventArgs) Handles rdoIn.CheckedChanged, rdoOut.CheckedChanged

Dim rdoWhere As RadioButton

'Determine which button was clicked and change where

rdoWhere = CType(sender, RadioButton)

PizzaWhere = rdoWhere.Text

**End Sub** 

In each of these routines, when an radio button is clicked (changing the Checked property), the value of the corresponding button's Text is loaded into the respective variable.

### btnBuild\_Click event

Private Sub btnBuild\_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles btnBuild.Click

'This procedure builds a message box that displays your pizza type

```
Dim Message As String
```

```
Dim I As Integer
```

```
Message = PizzaWhere + ControlChars.Cr
```

'Check each topping using the array we set up

```
For I = 1 To 6
```

If Topping(I).Checked Then

Message += Topping(I).Text + ControlChars.Cr

End If

Next I

MessageBox.Show(Message, "Your Pizza", MessageBoxButtons.OK)

This code forms the first part of a message for a message box by concatenating the pizza size, crust type, and eating location (recall **ControlChars.Cr** is a constant representing a 'carriage return' that puts each piece of ordering information on a separate line).


Next, the code cycles through the six topping check boxes (defined by our **Topping** array) and adds any checked information to the message. The code then displays the pizza order in a message box.

# btnExit\_Click event

Private Sub btnExit\_Click(ByVal sender As Object, ByVal e As System.EventArgs) Handles btnExit.Click

Me.Close()

## Get the application working



Then, when I click Build Pizza



### Exercise:

- 1. Add a new program button that resets the order form to the initial default values. You'll have to reinitialize the three global variables, reset all check boxes to unchecked, and reset all three radio button groups to their default values.
- 2. Modify the code so that if no toppings are selected, the message "Cheese Only" appears on the order form. You'll need to figure out a way to see if no check boxes were checked.

### ListBox Control

Check boxes are useful controls for selecting items from a list. But, what if your list has 100 items? Do you want 100 check boxes? No, but fortunately, there is a tool that solves this problem.

A **Listbox** control displays a list of items (with as many items as you like) from which the user can select one or more items.

If the number of items exceeds the number that can be displayed, a scroll bar is automatically added.

Both single item and multiple item selections are supported.

### **ListBox Properties:**

Name	Gets or sets the name of the list box (three letter prefix for list box name is lst).			
BackColor	Get or sets the list box background color.			
Font	Gets or sets font name, style, size.			
ForeColor	Gets or sets color of text.			
Items	Gets the Items object of the list box.			
SelectedIndex	Gets or sets the zero-based index of the currently selected item in a list box.			
SelectedIndices	Zero-based array of indices of all currently selected items in the list box.			
SelectedItem	Gets or sets the currently selected item in the list box.			
SelectedItems	Selected Items object of the list box.			
SelectionMode	Gets or sets the method in which items are selected in list box (allows single or multiple selections).			

**Sorted** Gets or sets a value indicating whether the items in list box are sorted

alphabetically.

**Text** Text of currently selected item in list box.

**TopIndex** Gets or sets the index of the first visible item in list box.

#### **ListBox Methods:**

**ClearSelected** Unselects all items in the list box.

**FindString** Finds the first item in the list box that starts with the specified string.

**GetSelected** Returns a value indicating whether the specified item is selected.

**SetSelected** Selects or clears the selection for the specified item in a list box.

#### **ListBox Events:**

**SelectedIndexChanged** Occurs when the SelectedIndex property has changed.

To add an item to a list box, use the **Add** method, to delete an item, use the **Remove** or **RemoveAt** method and to clear a list box use the **Clear** method. For our example list box, the respective commands are:

Add Item: **IstExample.Items.Add(**ItemToAdd**)** 

Delete Item: IstExample.Items.Remove(ItemToRemove)

lstExample.Items.RemoveAt(IndexofItemToRemove)

Clear list box: **IstExample.Items.Clear** 

List boxes normally list string data types, though other types are possible. Note, when removing items, that indices for subsequent items in the list change following a removal.

In a similar fashion, the **SelectedItems** object has its own properties to specify the currently selected items in the list box Of particular use is **Count** which tells you how many items are selected. This value, in conjunction with the SelectedIndices array, identifies the set of selected items.

The **SelectionMode** property specifies whether you want single item selection or multiple selections. When the property is **SelectionMode.One**, you can select only one item (works like a group of option buttons).

When the SelectionMode property is set to **SelectionMode.MultiExtended**, pressing <Shift> and clicking the mouse or pressing <Shift> and one of the arrow keys extends the selection from the previously selected item to the current item.

Pressing <Ctrl>and clicking the mouse selects or deselects an item in the list. When the property is set to **SelectionMode.MultiSimple**, a mouse click or pressing the spacebar selects or deselects an item in the list.

### ComboBox Control

The **ListBox** control is equivalent to a group of check boxes (allowing multiple selections in a long list of items).

The equivalent control for a long list of radio buttons is the **ComboBox** control. The ComboBox allows the selection of a single item from a list. And, in some cases, the user can type in an alternate response.

#### **ComboBox Properties:**

ComboBox properties are nearly identical to those of the ListBox, with the deletion of the **SelectionMode** property and the addition of a **DropDownStyle** property.

**Name** Gets or sets the name of the combo box (three letter prefix for combo box name is **cbo**).

**BackColor** Get or sets the combo box background color.

**DropDownStyle** Specifies one of three combo box styles.

**Font** Gets or sets font name, style, size.

**ForeColor** Gets or sets color of text.

**Items** Gets the Items object of the combo box.

**MaxDropDownItems** Maximum number of items to show in dropdown portion.

**SelectedIndex** Gets or sets the zero-based index of the currently selected item in list box portion.

**SelectedItem** Gets or sets the currently selected item in the list box portion.

**SelectedText** Gets or sets the text that is selected in the editable portion of combo box.

**Sorted** Gets or sets a value indicating whether the items in list box portion are sorted alphabetically.

**Text** String value displayed in combo box.

#### **ComboBox Events:**

KeyPress Occurs when a key is pressed while the combo box has focus.

**SelectedIndexChanged** Occurs when the SelectedIndex property has changed.

The **Items** object for the ComboBox control is identical to that of the ListBox control. You add and remove items in the same manner and values are read with the same properties.

The **DropDownStyle** property has three different values. The values and their description are:


#### **Value Description**

- DropDown
   Text portion is editable; drop-down list portion.
- DropDownList Text portion is not editable; drop-down list portion.
- Simple The text portion is editable. The list portion is always visible. With this value, you'll want to resize the control to set the list box portion height.

## Example - Flight Planner

Start a new project. In this example, you select a destination city, a seat location, and a meal preference for airline passengers.

Place a list box, two combo boxes, three labels and two buttons on the form. The form should appear similar to this:



Set the form and object properties:

Form1:

Name frmFlight

FormBorderStyle FixedSingle

StartPosition CenterScreen

Text

Flight Planner

ListBox1:

Name IstCities

Sorted True

ComboBox1:

Name cboSeat

DropDownStyle DropdownList

ComboBox2:

Name cboMeal DropDownStyle Simple [Blank]

(You'll want to resize this control after setting properties).

Label1:

Text Destination City

Label2:

Text Seat Location

Label3:

Text Meal Preference

Button1:


Name btnAssign Text &Assign

**Button2**:

Name btnExit

Text E&xit

Now, the form should look like this:



### Use this code in the Form\_Load procedure

Private Sub frmPlanner\_Load(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles MyBase.Load 'Add city names to list box lstCities.Items.Clear() lstCities.Items.Add("San Diego") lstCities.Items.Add("Los Angeles") lstCities.Items.Add("Orange County") lstCities.Items.Add("Ontario") lstCities.Items.Add("Bakersfield") lstCities.Items.Add("Oakland") lstCities.Items.Add("Sacramento") lstCities.Items.Add("San Jose")

lstCities.Items.Add("San Francisco") lstCities.Items.Add("Eureka") lstCities.Items.Add("Eugene") lstCities.Items.Add("Portland") lstCities.Items.Add("Spokane") lstCities.Items.Add("Seattle") **IstCities.SelectedIndex = 0** 

'Add seat types to first combo box cboSeat.Items.Add("Aisle") cboSeat.Items.Add("Middle") cboSeat.Items.Add("Window") cboSeat.SelectedIndex = 0

```
'Add meal types to second combo box
  cboMeal.Items.Add("Chicken")
  cboMeal.Items.Add("Mystery Meat")
  cboMeal.Items.Add("Kosher")
  cboMeal.Items.Add("Vegetarian")
  cboMeal.Items.Add("Fruit Plate")
  cboMeal.Text = "No Preference"
 End Sub
This code simply initializes the list box and the list box portions of the two combo boxes.
```

### Use this code in the btnAssign\_Click event

Private Sub btnAssign\_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles btnAssign.Click

'Build message box that gives your assignment

Dim Message As String

Message = "Destination: " + IstCities.Text + ControlChars.Cr

Message += "Seat Location: " + cboSeat.Text + ControlChars.Cr

Message += "Meal: " + cboMeal.Text + ControlChars.Cr

MessageBox.Show(Message, "Your Assignment", MessageBoxButtons.OK, MessageBoxIcon.Information)

**Fnd Sub** 


When the **Assign** button is clicked, this code forms a message box message by concatenating the selected city (from the list box **IstCities**), seat choice (from **cboSeat**), and the meal preference (from **cboMeal**).

### Use this code in the **btnExit\_Click** event

Private Sub btnExit\_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles btnExit.Click

Me.Close()

### Run the application. Here's my screen with choices I made:



### And, after clicking **Assign**, I see:



## After completing this class, you should understand:

- How to use the MessageBox dialog assigning messages, icons and buttons
- Useful properties, events, and methods for the form, button, text box, label, check box, and radio button controls
- Where the above listed controls can and should be used
- How GroupBox and Panel controls are used to group controls, particularly radio buttons
- How several events can be handled by a single event procedure
- The concept of 'control arrays' and how to use them
- How to use list box and combo box controls

## Exercise - Customer Database Input Screen

#### **Customer Database Input Screen**

A new sports store wants you to develop an input screen for its customer database. The required input information is:

- 1. Name
- 2. Age
- 3. City of Residence
- 4. Sex (Male or Female)
- 5. Activities (Running, Walking, Biking, Swimming, Skiing and/or In-Line Skating)
- 6. Athletic Level (Extreme, Advanced, Intermediate, or Beginner)

Set up the screen so that only the Name and Age (use text boxes) and, perhaps, City (use a combo box) need to be typed; all other inputs should be set with check boxes and radio buttons. When a screen of information is complete, display the summarized profile in a message box. This profile message box should resemble this:

